



EMERGENCY RESPONDER WARNING SYSTEM


Wireless Emergency Vehicle
Warning Systems with
Remote Activation

EMERGENCY RESPONDER WARNING SYSTEM

The solar-powered Emergency Responder Warning System provides notification to traffic when an emergency vehicle is exiting a station. It can be activated remotely from the base station mounted in the building and/or with optional key fob.

LED ENHANCED SIGNS and LED BEACONS

2 X 300mm (12") AMBER LED SIGNAL MODULES, BLACK POLYCARBONATE HOUSING



LED ENHANCED SIGNS

1 X FIRE TRUCK SYMBOL - 75 x 75 cm, FLUORESCENT YELLOW, 8 YELLOW LEDS PER SIGN




OTHER SIGNS AVAILABLE

HOSPITAL

AMBULANCE STATION


KEY FOB

THE BEACONS CAN BE ACTIVATED REMOTELY WITH AN OPTIONAL KEY FOB. THE FOB MUST BE WITHIN 200FT (61M) OF THE BASE STATION TO ACTIVE THE SYSTEM



INSIDE CONTROL UNIT

AC POWERED, WALL MOUNTED, WITH ANTENNA. ACTIVATES THE ADVANCED WARNING SYSTEM



1-866-466-4836 info@lanelight.com